

## INSTALLATION USING FIXING POST SCREWS

1. Drill Hole approx. 8mm / 9mm
2. Screw Fixing Posts Screw into drilled hole leaving 3mm between post and shoulder of screw (to allow for tensioning)
3. Cut cable to correct length.
4. Thread the Through Cap on to cable
5. Push cable into top of Fixing Post Screw as far as possible
6. Using pre-assembled grub screws tighten as much as possible with Allen Keys
7. Repeat the above at the other end of the cable (if using both Right & Left Hand)
8. Simple screw fixing post Screws in opposite directions to desired tension
9. Push on the Through Cap
10. JOB DONE