


# HOW TO GUIDE

# **MEASURING GUIDE FOR HORIZONTAL CABLES**



#### **STEP 01**

Measure the first post to the second post, including the width of the posts themselves and an additional 100mm. Repeat this step for each cable run. Once this is done you will need to identify the start and end points as you'll need an end collar kit for these sections.



#### **STEP 02**

If you have any posts that are fixed to a solid structure, you'll need include a fixing post screw instead of an end collar. Any posts that aren't corners or fixed to a solid structure these are classed as internal posts.




## **STEP 03**

In order to maintain tension you need to install a through collar kit at least once every 3m. Where through collar kits aren't needed, post inserts are used for internal posts.



## **STEP 04**

On corner posts, the cables will meet in the centre of the post. Simply run the cable through the centre of the post using an end collar, but DO NOT tighten yet. Then drill another hole at 90 degrees and fit the other cable using an end collar.



#### **STEP 05**

Finally, count how many runs of cable you want. You can order your cable runs online or record the details and send them to us via email.